

TUBE MIC PREAMPLIFIER CHANNEL 1

GAIN (0-10) **LEVEL** (0-10)

INSTRUMENT **INPUT** (Instrument, Mic, 48V) **PHASE** (-, +) **LOW-CUT** (Off, 80Hz, 160Hz)


TUBE MIC PREAMPLIFIER CHANNEL 2

GAIN (0-10) **LEVEL** (0-10)

INSTRUMENT **INPUT** (Instrument, Mic, 48V) **PHASE** (-, +) **LOW-CUT** (Off, 80Hz, 160Hz)

INPUT
2 1

OUTPUT
2 1

DUAL CHANNEL TUBE PRE / SN. 1-2011